

ADVENT CHYRVCH Installation Instructions:

- Remove factory 8.4 inch screen by removing the trim bezel and 4 retaining screws.
- Unplug the 22 pin cable, plug in the T-Harness, and reconnect to the panel.
- Connect rear view camera video cable to RCA and secure with tape.

VEHICLE MUST BE PROGRAMMED FOR CAMERA TO WORK.

CAMERA SHOULD BE POWERED TO ACC FOR BEST RESULTS. DO NOT CONNECT CAMERA POWER LEADS TO LED TAIL LIGHT SYSTEMS AS THIS CAN CAUSE ERROR CODES AND SERVICE CODES TO BE SET IN THE VEHICLE DUE TO ADDED CURRENT DRAIN.

DEALER PROGRAMMING INSTRUCTIONS

Vehicle VIN Number must be updated with the sales code of the added accessory in order to turn on the option and view the camera. Using the DealerCONNECT website and the Scantool follow the procedure below:

- 1: Log onto <https://dealerconnect.chrysler.com>, enter your dealer sign in information.
- 2: In the Vehicle Options screen under the "Global Claim System" category in the "SERVICE" tab, enter the VIN # and add the sales code XAC (PARK VIEW REAR BACK-UP CAMERA) as a "Dealer Installed Option".
- 3: Confirm the new code has been successfully added to the VIN with the ScanTool connected to both the internet (either by cable or wireless) and the vehicle.
- 4: Using the ScanTool Select the VEHICLE PREPERATION and then select RESTORE VEHICLE CONFIGURATION.
- 5: Follow the step by step instructions on the ScanTool to complete the "Park View Rear Back-Up Camera" vehicle configuration.
- 6: Confirm proper operation of the Camera.

This cable works with the following vehicles with and 8.4 inch screen:

- 2012-2014 Charger
- 2012-2014 Journey
- 2012-2014 300/300C

NOTE: OEM Option codes and wiring can change at any time. These instructions were accurate at time of printing. For questions contact Technical Support at 800-323-4815.

Size: 200*230 mm
Material: Both-side coated paper 127g