


Video Harness

5 PIN (F)



CAM_RIGHT

CAM_LEFT

Right Camera Trigger

Left Camera Trigger

Ground

USB Harness


4 PIN (M)



USB

Rear Cam & Power Harness

7 PIN (M)



Rear Camera Trigger

Rear Camera

Battery

Accessory

Ground

GPS Antenna Harness

MCX Connector
(M)



GPS Antenna

For technical support:

1-800-225-6074

or visit

www.VOXXUniversity.com